
AZ3

Extra low voltage
servo drive for
brushless and
DC motors



TEM Electric Motors S.r.l.

Via Berretta,1

42024 Castelnovo di Sotto (RE)

Phone +39 0522.68.27.23

P.I. IT01978390357

Index

1. SAFETY PRECAUTIONS.....	6
1.1. Operating limits	6
1.2. Handling.....	7
1.3. Transportation and installation	8
1.4. Wiring	9
1.5. Operations.....	10
1.6. Modification of parameters	10
1.7. Maintenance and inspection	11
1.8. Disposal.....	11
2. GENERAL INFORMATION.....	12
2.1. Full specifications	12
3. INSTALLATION AND WIRINGS.....	13
3.1. Installation environment	13
3.2. Mechanical installation.....	13
3.3. Mechanical drawings.....	13
3.4. Electrical connections.....	14
3.4.1. Lever terminal block X1 – Power.....	15
3.4.2. X2-A connector – Auxiliary outputs.....	16
3.4.3. X2-B connector – Auxiliary outputs.....	17
3.4.4. X3-A connector – Logic inputs/outputs.....	18
3.4.5. X3-B connector – Logic inputs/outputs.....	20
3.4.6. X3-A and X3-B schematics and warnings.....	21
3.4.7. X4-A connector – Communication (RJ45).....	23
3.4.8. X4-B connector – Communication (RJ45).....	24
3.4.9. X5 connector – Position sensors (high density DSUB-15)	25
4. DRIVE CONFIGURATIONS	27
4.1. Drive data	28
4.1.1. parameters	28
4.1.2. Configurations	28
4.2. Motor data.....	29
4.2.1. Parameters	29
4.2.2. Configurations	29

4.3.	Factors	31
4.3.1.	Parameters	31
4.3.2.	Configurations	31
4.4.	Analogic set point	34
4.4.1.	Parameters	34
4.4.2.	Configurations	34
4.5.	Digital commands	36
4.5.1.	Parameters	36
4.5.2.	Configurations	37
4.6.	Outputs feedback	38
4.6.1.	Parameters	38
4.6.2.	Configurations	38
4.7.	Electromechanical brake	39
4.7.1.	Parameters	39
4.7.2.	Configuration	39
4.8.	Start-up option	41
4.8.1.	Parameters	41
4.8.2.	Configuration	41
4.9.	TDI option	41
4.9.1.	Parameters	41
4.9.2.	Configurations	41
4.10.	Braking behaviour	42
4.10.1.	Parameters	42
4.10.2.	Configurations	42
4.11.	Emulated encoder	43
4.11.1.	Parameters	43
4.11.2.	Configurations	43
4.12.	Motor thermistor	44
4.12.1.	Parameters	44
4.12.2.	Configurations	44
4.13.	Torque limit	44
4.13.1.	Parameters	44
4.13.2.	Configurations	44

5. OPERATING MODES	45
5.1. Profile velocity mode.....	45
5.1.1. Parameters	45
5.1.2. Configuration.....	45
5.2. Profile position mode	47
5.2.1. Parameters	47
5.2.2. Configurations	47
5.3. Profile torque mode	49
5.3.1. Parameters	49
5.3.2. Configurations	49
5.4. Drive commands.....	51
5.4.1. Parameters	51
5.4.2. Configurations	51
5.5. PID tuning	52
6. PARAMETERS TABLE	54
6.1. Holding registers.....	54
6.2. Input registers.....	58
6.3. Coils	59
7. ERRORS AND DIAGNOSTICS	60
7.1. Parameters	60
7.2. Diagnostic	61
8. TROUBLESHOOTING	62
8.1. Parameters	62
8.2. Problem solving	62
9. MAINTENANCE AND INSPECTION	64
10. DISPOSAL	64

INDICE DELLE REVISIONI						
Rev.	Par.	Descrizione della modifica	Data	R	V	A
0.1	-	Draft	11/09/2018	mb		
0.2	-	CAN addresses updated	28/01/2020	mb		




Read carefully this manual before using the drive.

TEM Drive reserves the right to change the information reported in this manual without prior notice because the product is in continuous evolution.

No part of this manual may be howsoever reproduced without previous consent by TEM Drive.

1. SAFETY PRECAUTIONS




Read carefully the following items so that you can safely use the drive avoiding causing injury to the operators, damaging the mechanic components driven by the drive or other objects in the area. Make sure you that all warnings are correctly observed.



MARKING	Meaning of the marking
	Prohibition. Do not do it.
	Obligation. Follow the instruction.
	Warning.

1.1. Operating limits




- Use the drive only in industrial application; do not use it where a possible fault can cause serious injury to human life, like nuclear plants, aviation, safety device, entertainment and medical.
- Use the drive only where a possible fault of the drive does not cause serious accidents or damages or use it only where safety equipment is applicable or a backup circuit device is provided outside the system.



1.2. Handling

 WARNING	
	<ul style="list-style-type: none">• Do not disassemble, modify or repair. This can cause electrical shock, fire and injury.• Do not touch the electronic drive components when power is on. This can result in electric shock or other injury.• Do not allow water or any other fluid to come in contact with the drive. This can result in electric shock or fire.
	<ul style="list-style-type: none">• Turn on the power only when the drive is closed in a proper insulating cabinet to avoid electric shock or other injury.• If the drive begins to emit smoke, an unusual odour, or unusual sounds, immediately disconnect the power. Continuous use of the drive in such a state may cause fire. Call your TEM Drive distributor for assistance and/or repair.• Always turn the power off if the drive is not used for long time. Leaks, dust and other material may cause malfunctions and if power is left on with the drive in that state, it may result in fire.




 CAUTION	
	<ul style="list-style-type: none">• Do not touch heatsink fins or discharge / braking resistors. These parts may be hot and can cause burning if you touch them.



1.3. Transportation and installation

 WARNING	
	<ul style="list-style-type: none">• Do not install or operate the drive if it is damaged. This can result in electrical shock or fire.• Do not place any inflammable objects near the drive. If an accident occurs in which flame is emitted, this could lead to fire.• Do not install in any location where the drive could come into contact with water or other fluids. This can result in electric shock or fire.
	<ul style="list-style-type: none">• Operate under the environmental conditions prescribed in this instruction manual. Operations under any other conditions may result in malfunction.• Install an emergency stop device that fits with system specifications. The drive alone cannot stop operation immediately, thus resulting in an accident or injury.




 CAUTION	
	<ul style="list-style-type: none">• Always turn the power off when removing the drive from its support.



1.4. Wiring

 WARNING	
	<ul style="list-style-type: none">• First shut off input power and wait at least 5 minutes before touching terminals and wires on equipment that is connected to drive power side. Touching the terminals and wires before that time could result in electrical shock.
	<ul style="list-style-type: none">• A qualified expert must do electrical construction work. Connection of input power by someone who does not have that expert knowledge may result in fire or electric shock.• Connect output terminals (motor side) correctly. Incorrect connections may result in injury or electric shock.• The following steps must be performed before wiring:<ul style="list-style-type: none">○ Turn off all input power.○ Wait at least 5 minutes and check to make sure that the on state LED is no longer lit.○ Use a tester that can measure DC voltage (60 V DC or more) and check to make sure that the voltage to the DC main circuits (across +VDC and -VDC) is 45 V or less. If these steps are not properly performed, the wiring will cause electrical shock.• Check to make sure that the input power voltage is within the limits of the rated power voltage indicated on the manual. If the input power voltage do not respect these conditions, this may result in fire.



 CAUTION	
	<ul style="list-style-type: none">• Do not attach devices with built-in capacitors (such as noise filters or surge absorbers) to the outputs (motor side) terminals. This could cause a fire

1.5. Operations




 WARNING	
	<ul style="list-style-type: none">• Do not overload the drive over its capabilities. The use of the drive over its maximum service factor may cause serious accidents through overheating and fire.• Do not touch terminals when electrical power is going to the drive even if the motor is stopped. Touching the drive terminal while power is connected to it may result in electrical shock.• Do not touch the drive when the hands are wet. Such action may result in electric shock.
	<ul style="list-style-type: none">• If parameters are set incorrectly, the drive may have some damage or unexpected movement. Be sure to set the drive parameters correctly.

 CAUTION	
	<ul style="list-style-type: none">• Use a motor that conforms to the specifications of the drive and power supply. If the motor being used does not conform to those specifications, not only will the motor not rotate correctly but also it may cause serious accidents through overheating and fire.



1.6. Modification of parameters

 WARNING	
	<ul style="list-style-type: none">• Do not modify parameters before reading carefully this manual. An incorrect set of the parameters can cause injury or accidents.

1.7. Maintenance and inspection

 WARNING	
	<ul style="list-style-type: none"> Do not replace parts. This could be cause of electric shock, fire and bodily injury. To replace parts, call your TEM drive distributor.
	<ul style="list-style-type: none"> The equipment must be inspected periodically. If the equipment is not inspected and maintained, errors and malfunctions may not be discovered and that could result in accidents. Before inspection performs the following steps <ul style="list-style-type: none"> Turn off all input power. Wait at least 5 minutes and check to make sure that the on state LED is no longer lit. Use a tester that can measure DC voltage (60 V DC or more) and check to make sure that the voltage to the DC main circuits (across +VDC and -VDC) is 45 V or less. Performing an inspection without carrying out these steps first could lead to electric shock.

1.8. Disposal

 WARNING	
	<ul style="list-style-type: none"> If you dispose of the drive, have it done by a specialist in industry waste disposal (*). If you dispose of the drive by yourself, this can result in explosion of capacitor or produce noxious gases, resulting in injury. <p>(*) Persons who specialize in the processing of waste and known as "industrial waste product collectors and transporters" or "industrial waste disposal persons". Please observe any applicable law, regulation, rule or ordinance for industrial waste disposal.</p>

2. GENERAL INFORMATION

AZ3 is an extra-low voltage drive designed for the control of AC/DC brushless motors and DC motors. The high versatility of this product is demonstrated by the various position feedbacks available (Hall, incremental encoder), the different kind of inputs (analog, digital and frequency) and outputs (digital, power PWM) and the communication interfaces (CAN, Modbus); furthermore it is available in both integrated and stand-alone versions. The drive can also operate with a secondary encoder input for direct axis control and can manage an electromechanical brake or a braking resistor without relay/contactator

The AZ3 manual is intended to be used with TEM Interface manual and Modbus RTU AZ3 manual.

2.1. Full specifications

FULL SPECIFICATIONS	
POWER STAGE	
Supply voltage	24 V to 60 V DC
Output current	30 A ÷ 60 A Peak (5s)
Technology	MOSFET integrated power module
TECHNICAL CHARACTERISTICS	
Operating temperature	-20 °C ÷ +40 °C
Motor types	Brushless AC, Brushless DC, DC motor
Position feedback	Hall Switches (120°), incremental encoder
CONTROL	
Control loops	Torque current, speed and position
Control modes	Digital inputs, analog input, DS402
DS402 modes	Profile velocity, profile torque, position profile
INPUTS	
Digital (isolated)	General purpose (24V), high-frequency (x2)
Analog	0 ÷ 10 V, ±10 V, 4 ÷ 20 mA
Torque Disabling	1 or 2 TD inputs
OUTPUTS	
Logic (isolated)	Configurable digital outputs (x2), emulated encoder
Power outputs with PWM (Pulse Width Modulation) control	Braking resistor, electromechanical brake
COMMUNICATIONS (ISOLATED)	
Communications protocol	CAN / CANopen DS402, Modbus RTU (over RS485), UART
PC SOFTWARE	
Parametrization	Basic & advanced views
Diagnostic	Virtual oscilloscope, monitor panel
Commands	Remote command panel

3. INSTALLATION AND WIRINGS



Read carefully the safety precautions reported in chapter 1.3 and in chapter 1.4 before wiring operations!

Carefully follow the instructions below, before installing the drive and integrate it into your system.

3.1. Installation environment

Remember that the drive is an electronic device; check carefully that the installation environment is appropriate:


- Do not install in any location with high temperature, high humidity, moisture condensation and freezing.
- Avoid installing location where there is the possibility of exposition to water, large amounts of dust, metallic fragments or corrosive gases.
- Operate in areas where the temperature is within the limit temperatures.
- Do not install in any location that can be subject to large amounts of vibrations.

3.2. Mechanical installation

During the installation of the drive, take care of distances between others objects in order that the wiring can be carried out easily and the drive can dissipate the heat generated during operation.


3.3. Mechanical drawings

In the following image the dimension of the drive are showed with all the measures in mm.




3.4. Electrical connections

During connection of terminals, work with power disabled. The image below shows AZ3 connectors.




3.4.1. LEVER TERMINAL BOCK X1 – POWER.

X1 is a WAGO 2716-105.




PIN	DESCRIPTION
1	U +M brushless motor U phase DC motor positive pole
2	V brushless motor V phase
3	W -M brushless motor W phase DC motor negative pole
4	-VDC Ground and positive supply
5	+VDC

The following image show X1 pin-out.




It is recommended to choose power cables in function of the current absorbed by the motor.

3.4.2.X2-A CONNECTOR – AUXILIARY OUTPUTS.




PIN	DESCRIPTION
1	EO-GND Ground for emulated encoder outputs
2	N.C Not connected
3	+VDC Positive supply for power output #1
4	POUT1 Power PWM output #1 (open drain MOSFET)
5	+VDC Positive supply for power output #2
6	POUT2 Power PWM output #2 (open drain MOSFET)


The following image shows X2-A pin-out.



Through power outputs, the drive can manage an electromechanical brake or braking resistor without relay/contactors.




3.4.3.X2-B CONNECTOR – AUXILIARY OUTPUTS.




PIN	DESCRIPTION
1	EO-CHA+ Emulated encoder output – CHA+
2	EO-CHA- Emulated encoder output – CHA-
3	EO-CHB+ Emulated encoder output – CHB+
4	EO-CHB- Emulated encoder output – CHB-
5	EO-CHZ+ Emulated encoder output – CHZ+
6	EO-CHZ- Emulated encoder output – CHZ-


The following image shows X2-B pin-out.



The schematics of channels output of emulated encoder is showed in the following images.




3.4.4.X3-A CONNECTOR – LOGIC INPUTS/OUTPUTS.



PIN	DESCRIPTION
1	AIN2- Differential analog input #2 – negative terminal
2	AIN2+ Differential analog input #2 – positive terminal
3	AGND Ground for analog inputs
4	DHF2+ Isolated digital input HF #2
5	DHF2- Isolated digital input HF #2 – ground
6	DOUT2+ Isolated digital output #2 –NPN BJT collector
7	DOUT2- Isolated digital output #2 –NPN BJT emitter
8	DIN2+ Isolated digital input #2
9	DIN4+ Isolated digital input #4
10	ENABL+ Isolated digital input DRIVE ENABLE (TDI +)
11	ENABL- Isolated digital input DRIVE ENABLE (TDI -) – ground


The following image show X3-A pin-out.



DRIVE ENABLE must be connected to the drive in order to enable the power stage.


Refer to chapter 3.4.6 in order to correctly connect digital outputs, digital inputs and analog inputs.

3.4.5.X3-B CONNECTOR – LOGIC INPUTS/OUTPUTS.



PIN	DESCRIPTION
1	AIN1- Differential analog input #1 – negative terminal
2	AIN1+ Differential analog input #1 – positive terminal
3	DGND Ground for digital inputs #1 – 2 – 3 – 4
4	DHF1+ Isolated digital input HF #1
5	DHF1- Isolated digital input HF #1 – ground
6	DOUT1+ Isolated digital output #1 –NPN BJT collector
7	DOUT1- Isolated digital output #1 –NPN BJT emitter
8	DIN1+ Isolated digital input #1
9	DIN3+ Isolated digital input #3
10	DIN5+ Isolated digital input #5
11	DIN5- Isolated digital input #5 – ground

The following image show X3-B pin-out.




Refer to chapter 3.4.6 in order to correctly connect digital outputs, digital inputs and analog inputs.

3.4.6.X3-A AND X3-B SCHEMATICS AND WARNINGS




Read carefully the following instruction, non-observance of this specification may damage the drive!


- AZ3 has six digital opto-isolated inputs with the following schematic. The input digital inputs voltage must be 24 V. In the images below two possible connection examples.



- AZ3 has two digital opto-isolated outputs with the following schematic. Do not exceed an input current of 50 mA. Non-observance of this specification may damage the drive. In the images below two possible connection examples.




- AZ3 has two analog inputs, whose input voltage must be between -10 V and +10 V.




3.4.7.X4-A CONNECTOR – COMMUNICATION (RJ45)

With X4-A it is possible to connect AZ3 with TEM interface.




PIN	DESCRIPTION
1	CANH
2	CANL
3	Ground for communication signals
4	RS485 for Modbus communication – B/-
5	RS485 for Modbus communication – A/+
6	UART for PC software communication – TX
7	UART for PC software communication – RX
8	Ground for communication signals

The following image show X4-A pin-out.




NOTE: Termination resistor is not integrated in the circuit. Contact your TEM drive distributor for termination resistor.

3.4.8.X4-B CONNECTOR – COMMUNICATION (RJ45)




PIN	DESCRIPTION
1	CANH
2	CANL
3	Ground for communication signals
4	RS485 for Modbus communication – B/-
5	RS485 for Modbus communication – A/+
6	Not connected
7	Not connected
8	Ground for communication signals

The following image show X4-B pin-out.




NOTE: Termination resistor is not integrated in the circuit. Contact your TEM drive distributor for termination resistor.

3.4.9.X5 CONNECTOR – POSITION SENSORS (HIGH DENSITY DSUB-15)




PIN	DESCRIPTION
1	Incremental encoder – CHA-
2	Hall signal – U
3	Hall signal – V
4	Not connected
5	Motor thermistor– pin #1
6	Incremental encoder – CHA+
7	Hall signal – W
8	Ground
9	Supply +5V DC
10	Not connected
11	Incremental encoder – CHB-
12	Incremental encoder – CHB+
13	Incremental encoder – CHZ-
14	Incremental encoder – CHZ+
15	Motor thermistor– pin #2


The following image show X5 pin-out.



The input stage schematic of channels of incremental encoder is showed in the image below:



The input stage schematic of channels of Hall encoder is showed in the image below:



Refer to chapter 4.2.2 for Hall sequence.

4. DRIVE CONFIGURATIONS



Read carefully the safety precautions reported in chapter 1.3 and in chapter 1.4 before wiring operations!

AZ3 has a wide set of parameters that allow to configure the drive. Be careful when configuring the drive because an incorrect set of the parameters can cause injury or accidents. It is possible to configure all the following parameters using TEM interface (refer to TEM interface manual). During normal operation (no error), the drive LED blinks and has a white colour. If the drive does not blink and has different colours, it is in fault condition (refer to chapter 7).

Once the drive has been configured with the selected parameters, these must be saved. In order to save parameters, set to 65766173h the parameter *Store all parameters*.

Variable	Type	Code	Unit	Default	Range	Can open address		Modbus logical address	
Store all parameters	UNS16	SV1	-	0	0÷1.0E9	INDEX SUB	1010h 01h	HR	449 450

4.1. Drive data

The drive data must be configured in order to avoid malfunctions or failures.

4.1.1.PARAMETERS

Variable	Type	Code	Unit	Default	Range	Can open address		Modbus logical address	
V bus max*	FLOAT	DD1	V	60	0÷100	INDEX SUB	203Dh	HR	60 61
Nominal current rms*	FLOAT	IC1	A	30	-100÷100	INDEX SUB	203Eh	HR	68 69
Alimentation power*	FLOAT	AD1	W	3.36	0÷1.0E6	INDEX SUB	2053h 02h	HR	318 319

*These parameters once changed, must be saved. The new value assigned to this parameter will become operational only after a power reset.

4.1.2.CONFIGURATIONS

Nominal current rms is the nominal current of the drive, *Alimentation power* is the power absorbed by the drive with power stage disabled and *V bus max* is the maximum input voltage. It is recommended to maintain the default values for *Nominal current rms* and *V bus max*, only *Alimentation power* must be changed because in function of the encoder the power absorption of the drive changes.

4.2. Motor data

AZ3 can control DC motors and AC Brushless motors with incremental encoder or Hall switches as feedback sensors.

4.2.1. PARAMETERS

Variable	Type	Code	Unit	Default	Range	Can open address		Modbus logical address	
Motor type*	UNS16	MTY1	-	10	0÷65535	INDEX SUB	6402h 00h	HR	176
Max motor speed	UNS32	SF1	User units	3000	0÷2.0E6	INDEX SUB	6080h 00h	HR	85 86
MOTOR POLES PAIR*	UNS16	DD5	-	4	0÷16	INDEX SUB	203Ah	HR	65
Motor rated torque*	UNS32	TC4	mNm	2300	0÷1.0E9	INDEX SUB	6076h	HR	273 274
Motor rated current*	UNS32	TC5	mA	16000	0÷1.0E9	INDEX SUB	6075h	HR	275 276
ENCODER TYPE	S16	DD2	-	0	0÷10	INDEX SUB	2039h	HR	62
Encoder phase* displacement	FLOAT	PHC3	[rad]	3.14	-6.28÷6.28	INDEX SUB	2052h 03h	HR	185 186
Phasing in progress	COIL	DF1	-	0	-	INDEX SUB	2018h (bit 0)	COIL	1
Start phasing	COIL	DF2	-	0	-	INDEX SUB	2018h (bit 1)	COIL	2
auto-phased motor*	COIL	DF6	-	0	-	INDEX SUB	2018h (bit 5)	COIL	6

*These parameters once changed, must be saved. The new value assigned to this parameter will become operational only after a power reset.


4.2.2. CONFIGURATIONS

It is necessary to set to 1 *Motor type* in order to control DC motor. *Motor type* can be set to all the others value in order to control a brushless motor but is advisable to set the variable to 10 as described in DS402 specification.


Motor rated torque and *Motor rated current* must be set in function of the motor nameplate data.

Through *ENCODER TYPE* it is possible to choice between Hall encoder (*ENCODER TYPE* equal to 2) and incremental encoder with Hall (*ENCODER TYPE* equal to 0).

Motors with Hall encoder, in order to work properly with AZ3, must be phased with the Hall states positioned relative to the U alignment as described in the image below (Hall states are in U, V, W sequence).



AZ3 can handle incremental encoder with Hall, with every displacement between U phase rising edge and zero mark. The displacement is configurable through *Encoder phase displacement*, for example if zero mark is positioned exactly on U phase rising edge, then *Encoder phase displacement* must be set to zero. In the following image is possible to understand how setting *Encoder phase displacement* in order to obtain the desired displacement.



EXAMPLE: if a motor has an incremental encoder with Hall with a displacement between U phase rising edge and zero mark of 180° (3.14 rad), it is sufficient to set *Encoder phase displacement* to 3.14.

AZ3 can perform an auto-phasing routine for motors with incremental encoder with Hall.

Prior to start with the auto-phasing routines, disconnect the motor from the load and if a brake is connected to the motor, disengage it with direct control as described in chapter 4.7. Factor parameters must be set properly before starting with auto-phasing routine.

In order to start the auto-phasing routines set to 1 *Phasing in progress* and wait until *Phasing in progress* become zero. After auto-phasing procedure is ended, save all the parameters and restarts the drive. At drive restart check that *auto-phased motor* is set to 1.

4.3. Factors

Factors calculation permits to configure the drive in function of the input references and the desired units of measure.

4.3.1. PARAMETERS

Variable	Type	Code	Unit	Default	Range	Can open address		Modbus logical address	
Gear ratio motor* revolution	UNS32	FS1	rounds	1	0÷400000	INDEX SUB	6091h 01h	HR	89 90
Gear ratio shaft* revolutions	UNS32	FS2	rounds	1	0÷400000	INDEX SUB	6091h 02h	HR	91 92
Velocity encoder* resolution motor revolutions	UNS32	FS3	round/s	1	0÷400000	INDEX SUB	6090h 02h	HR	93 94
Velocity encoder* resolution increments per second	UNS32	FS4	Incr/s	8192	0÷400000	INDEX SUB	6090h 01h	HR	95 96
Feed constant feed*	UNS32	FS5	-	1	0÷400000	INDEX SUB	6092h 01h	HR	97 98
Feed constant shaft* revolutions	UNS32	FS6	rounds	1	0÷400000	INDEX SUB	6092h 02h	HR	99 100
Position encoder* resolution motor revolutions	UNS32	FS9	rounds	1	0÷400000	INDEX SUB	608Fh 02h	HR	105 106
Position encoder* resolutions encoder increments	UNS32	FS10	-	8192	0÷400000	INDEX SUB	608Fh 01h	HR	107 108
Velocity factor* numerator	S16	FS11	-	60	0÷32767	INDEX SUB	6094h 01h	HR	109
Velocity factor* denominator	S16	FS12	-	1	0÷32767	INDEX SUB	6094h 02h	HR	110
Polarity	UNS16	FS13	-	0	0÷65536	INDEX SUB	607Eh	HR	111

*These parameters once changed, must be saved. The new value assigned to this parameter will become operational only after a power reset.

4.3.2. CONFIGURATIONS

Performs the following steps to set factors in order to configure the drive starting from the encoder to the linear actuator.

- *Position encoder resolution motor revolutions* and *Position encoder resolutions encoder increments* perform the calculation of resolution of the encoder mounted on the motor.

$$\text{Position encoder resolution} = \frac{\text{Position encoder resolutions encoder increments}}{\text{Position encoder resolution motor revolutions}}$$

The drive counts every edge of the two encoder channels, so there is a factor 4 between encoder resolution and motor revolutions .

EXAMPLE: the application has an encoder with 2048 pulses for round, *Position encoder resolutions encoder increments* must be set to 8192 and *Position encoder resolution motor revolutions* must be set to 1.

- Use *Gear ratio motor revolution* and *Gear ratio shaft revolutions* in order to calculate the gear ratio.

$$\text{Gear ratio factor} = \frac{\text{Gear ratio motor revolution}}{\text{gear ratio shaft revolutions}}$$

EXAMPLE: with a gearbox with reduced ratio of 30, for every gearbox revolution the motor does 30 revolutions.

In this case:

$$\text{Gear ratio motor revolution} = 30, \quad \text{gear ratio shaft revolutions} = 1$$

$$\text{Gear ratio factor} = \frac{30}{1}$$

- Use *Feed constant feed* and *Feed constant shaft revolutions* in order to calculate the measurement distance per one revolution of the output shaft of the gearbox.

$$\text{Feed constant} = \frac{\text{Feed constant feed}}{\text{Feed constant shaft revolutions}}$$

EXAMPLE: if every revolutions of the shaft of the gearbox (or of the motor if there are not gearboxes) correspond in a linear movement of 11.5 user unit:

$$\text{Feed constant feed} = 23, \quad \text{Feed constant shaft revolutions} = 2$$

$$\text{Gear ratio factor} = \frac{23}{2}$$

It is not possible to write directly 11.5 in *Feed constant feed* because the type of this parameter is unsigned.

- Use *Velocity encoder resolution motor revolutions* and *Velocity encoder resolution increments per second* in order to calculate the velocity encoder resolutions.

$$\text{Velocity encoder resolution} = \frac{\text{Velocity encoder resolution increments per seconds}}{\text{Velocity encoder resolution motor revolutions}}$$

Velocity encoder resolution is different from *Position encoder resolution* only if two different encoder are used for position feedback and for velocity feedback. In all the others cases those two values must be equal.

As described for *Position encoder resolution* the drive counts every edge of the two encoder channel, so take care about factor 4. With Hall encoder this value is automatically set in function of the motor poles, but however is recommended to set it in the appropriate way.

- *Velocity factor numerator* and *Velocity factor denominator* are used in order to match the velocity unit to the user-defined velocity unit.

$$\text{Velocity value} = \frac{\text{Velocity internal value} * \text{feed constant}}{\text{Velocity encoder resolution} * \text{gear ratio}} * \frac{\text{Velocity factor numerator}}{\text{Velocity factor denominator}}$$

EXAMPLE: if the user want to use rpm instead of rps, *Velocity factor numerator* must be set to 60 and *Velocity factor denominator* must be set to 1.

If different units of measure between position measurement and velocity measurement are needed, the advice is to set before feed constant for reach the desired position unit of measure and then with *Velocity factor numerator* and *Velocity factor denominator* adjust velocity unit of measure.

$$\textit{Position value} = \frac{\textit{Position internal value} * \textit{feed constant}}{\textit{Position encoder resolution} * \textit{gear ratio}}$$

4.4. Analogic set point

The AZ3 drive has two configurable analog inputs (refer to chapters 3.4.4, 3.4.5 and 3.4.6).

4.4.1. PARAMETERS

Variable	Type	Code	Unit	Default	Range	Can open address		Modbus logical address	
User range 1	FLOAT	AI1	-	1000	-1.0E9÷1.0E9	INDEX SUB	2045h 02h	HR	249 250
Offset 1	FLOAT	AI2	-	0	-1.0E9÷1.0E9	INDEX SUB	2045h 03h	HR	251 252
Zero threshold 1	UNS16	AI3	-	5	0÷65535	INDEX SUB	2045h 04h	HR	253
User range 2	FLOAT	AI4	-	1000	-1.0E9÷1.0E9	INDEX SUB	2046h 02h	HR	254 255
Offset 2	FLOAT	AI5	-	-500	-1.0E9÷1.0E9	INDEX SUB	2046h 03h	HR	256 257
Zero threshold 2	UNS16	AI6	-	1	0÷65535	INDEX SUB	2046h 04h	HR	258
Selector 1	UNS8	AI7	-	2	0÷255	INDEX SUB	2045h 01h	HR	259L
Selector 2	UNS8	AI8	-	4	0÷255	INDEX SUB	2046h 01h	HR	259H
AI Mult 1	FLOAT	AI9	-	0.1	-1.0E9÷1.0E9	INDEX SUB	-	HR	260 261
AI Mult 2	FLOAT	AI10	-	0.9	-1.0E9÷1.0E9	INDEX SUB	-	HR	262 263
AI filter time	UNS32	AI11	0.1*ms	10	0÷200000	INDEX SUB	-	HR	264 265
SET POINT SELECTOR	S16	DD3	-	0	0÷10	INDEX SUB	2038h	HR	63

4.4.2. CONFIGURATIONS

To activate the analog input module, *SET POINT SELECTOR* must be set to 1, or to 3 for the combined use with digital inputs.

The adaptation of the analogic inputs in order to generate a set point is done through the following three steps.

- Inputs are filtered through the following equation:

$$\text{Filtered Value} = \text{New readed value} * \text{AIMult1} + \text{Old value} * \text{AIMult2}$$

It is also possible to configure how many samples are usefull for set point calculation through *AI filter time*. In *AI filter time* must be inserted the set point update time in tenths of millisecond. It is recommended to keep a minimum value of at least 10.

- Inputs are adapted to desired user range through the following equation:

$$\text{Setpoint} = \text{FilteredValue} * \frac{1}{\text{ADC range}} * \text{User range} + \text{offset}$$

- The value of the controlled variable (variable connected to analog input) is set to 0 if the value readed from ADC is below the value contained in *Zero threshold*.

Two selectors (*Selector 1 and Selector 2*) connect the adapted analog input to the preferred variable.

- 0: unused.
- 1: *Target velocity* (refer to chapter 5.1).
- 3: *Target position* (refer to chapter 5.2).
- 4: *Target torque* (refer to chapter 5.3).

EXAMPLE: in order to control the speed of the motor through the analog input 1, from -1500 rpm to 1500 rpm, with an input voltage variable form -10V to 10V, the analog input variables must be configured as follow:

Selector 1 = 1

User range 1 = 3000

Offset 1 = 0

The other variables can be left to the default values.

4.5. Digital commands

Four digital inputs can be used in order to control the behaviors of the drive (refer to chapters 3.4.4, 3.4.5 and 3.4.6). It is possible to configure both the operation to do at the rising edge of the digital input and the operation to do at the falling edge.

4.5.1. PARAMETERS

Variable	Type	Code	Unit	Default	Range	Can open address		Modbus logical address	
DI1 rise selector	UNS8	DI1	-	0	0÷255	INDEX SUB	2047h 01h	HR	320L
DI1 fall selector	UNS8	DI2	-	0	0÷255	INDEX SUB	2047h 02h	HR	320H
DI2 rise selector	UNS8	DI3	-	0	0÷255	INDEX SUB	2047h 03h	HR	321L
DI2 fall selector	UNS8	DI4	-	0	0÷255	INDEX SUB	2047h 04h	HR	321H
DI3 rise selector	UNS8	DI5	-	0	0÷255	INDEX SUB	2047h 05h	HR	322L
DI3 fall selector	UNS8	DI6	-	0	0÷255	INDEX SUB	2047h 06h	HR	322H
DI4 rise selector	UNS8	DI7	-	0	0÷255	INDEX SUB	2047h 07h	HR	323L
DI4 fall selector	UNS8	DI8	-	0	0÷255	INDEX SUB	2047h 08h	HR	323H
Speed value 1	S32	DI9	-	0	-1.0E9÷1.0E9	INDEX SUB	2048h	HR	324 325
Speed value 2	S32	DI10	-	0	-1.0E9÷1.0E9	INDEX SUB	2049h	HR	326 327
Position value 1	S32	DI11	-	0	-1.0E12÷1.0E12	INDEX SUB	204Ah	HR	328 329
Position value 2	S32	DI12	-	0	-1.0E12÷1.0E12	INDEX SUB	204Bh	HR	330 331
Torque value 1	S16	DI13	-	0	-10000÷10000	INDEX SUB	204Ch	HR	332
Torque value 2	S16	DI14	-	0	-10000÷10000	INDEX SUB	204Dh	HR	333
SET POINT SELECTOR	S16	DD3	-	0	0÷10	INDEX SUB	2038h	HR	63

4.5.2.CONFIGURATIONS

To activate the digital input module, *SET POINT SELECTOR* must be set to two, or to three for the combined use with analog inputs.

Every digital input edge can be configured as described in the following table.

Value of selector	function	Operating mode*
0	Unused	-
1	<i>Control word</i> set to 15 (power stage enabled) and <i>Target velocity</i> set to the value contained in <i>Speed value 1</i>	Profile velocity
2	<i>Control word</i> set to 15 (power stage enabled) and <i>Target velocity</i> set to the value contained in <i>Speed value 2</i>	Profile velocity
3	<i>Control word</i> set to 15 (power stage enabled) and <i>Target position</i> set to the value contained in <i>Position value 1</i>	Profile position
4	<i>Control word</i> set to 15 (power stage enabled) and <i>Target position</i> set to the value contained in <i>Position value 2</i>	Profile position
5	<i>Control word</i> set to 15 (power stage enabled) and <i>Target torque</i> set to the value contained in <i>Torque value 1</i>	Profile torque
6	<i>Control word</i> set to 15 (power stage enabled) and <i>Target torque</i> set to the value contained in <i>Torque value 2</i>	Profile torque
7	<i>Target velocity</i> set to 0	Profile velocity
8	<i>Target torque</i> set to 0	Profile torque
9	<i>Control word</i> set to 6 (power stage disabled) and <i>Target velocity</i> set to 0	Profile velocity
10	<i>Control word</i> set to 6 (power stage disabled) and target torque set to 0	Profile torque
11	Position reset (<i>Position actual value</i> set to 0)	Position profile
12	<i>Control word</i> set to 15** (power stage enabled)	All
13	<i>Control word</i> set to 7** (power stage disabled)	All
14	<i>Control word</i> set to 6** (power stage disabled)	All
15	<i>Control word</i> set to 2** (power stage disabled)	All
16	<i>Control word</i> set to 0 (quick stop)** (power stage disabled)	All
17	Reset error	All

*refer to chapter 5

**To understand the effects of these operations refers to chapter 5.4

EXAMPLE: it is possible to enable the power stage and set the speed to 3000 with digital input 1, disable the power stage with digital input 2, set the speed to 500 and enable the power stage at the rising edge of digital input 3, set speed to 0 and disable power at the falling edge of digital input 3.

Speed value 1 = 3000

DI1 rise selector = 1

DI2 rise selector = 14

Speed value 2 = 500

DI3 rise selector 1 = 2

DI3 fall selector 1 = 9

4.6. Outputs feedback

Az3 has two configurable digital outputs (refer to chapters 3.4.4, 3.4.5 and 3.4.6).

4.6.1.PARAMETERS

Variable	Type	Code	Unit	Default	Range	Can open address		Modbus logical address	
Output 1 selector	UNS8	OF1	-	0	0÷255	INDEX SUB	204Eh 02h	HR	187L
Output 2 selector	UNS8	OF2	-	0	0÷255	INDEX SUB	204Eh 03h	HR	187H

4.6.2.CONFIGURATIONS

Through *Output 1 selector* and *Output 2 selector* is possible to choice which feedback monitor connect to the output.

- 0: unused.
- 1: output set to 1 if drive works properly and to 0 in case of fault.
- 2: output set to 1 when position target is reached (refer to chapter 5.2).
- 3: output set to 1 when torque limit reached (refer to chapter 4.13).
- 4: Complementary of case 1.

4.7. Electromechanical brake

Az3 could directly handle an electromechanical brake (refer to chapter 3.4.2).

4.7.1. PARAMETERS

Variable	Type	Code	Unit	Default	Range	Can open address		Modbus logical address	
AUX PWM OUT 1 SEL	UNS8	AXO1	-	0	0÷5	INDEX SUB	204Eh 05h	HR	266L
AUX PWM OUT 2 SEL	UNS8	AXO2	-	0	0÷5	INDEX SUB	204Eh 06h	HR	266H
BRAKE 1 MODE SEL	UNS8	AXO3	-	1	0÷100	INDEX SUB	204Eh 07h	HR	267L
BRAKE 1 POW VALUE	UNS8	AXO4	%	100	0÷5	INDEX SUB	204Fh 02h	HR	267H
Brake activation	COIL	DRF8	-	0	-	INDEX SUB	2019h (bit 7)	COIL	24
Brake value	COIL	DRF9	-	0	-	INDEX SUB	2019h (bit 8)	COIL	25
START	COIL	BKS1	-	0	-	INDEX SUB	201Bh (bit 0)	COIL	81
NOT READY TO SWITCH ON	COIL	BKS2	-	0	-	INDEX SUB	201Bh (bit 1)	COIL	82
SWITCH ON DISABLED	COIL	BKS3	-	0	-	INDEX SUB	201Bh (bit 2)	COIL	82
READY TO SWITCH ON	COIL	BKS4	-	0	-	INDEX SUB	201Bh (bit 3)	COIL	83
SWITCHED ON	COIL	BKS5	-	0	-	INDEX SUB	201Bh (bit 4)	COIL	84
OPERATION ENABLED	COIL	BKS6	-	1	-	INDEX SUB	201Bh (bit 5)	COIL	85
QUICK STOP ACTIVE	COIL	BKS7	-	0	-	INDEX SUB	201Bh (bit 6)	COIL	86
FAULT	COIL	BKS8	-	0	-	INDEX SUB	201Bh (bit 7)	COIL	87
FAULT REACTION ACTIVE	COIL	BKS9	-	0	-	INDEX SUB	201Bh (bit 8)	COIL	88
brake disengage time	UNS16	DRS3	ms	0	0÷65535	INDEX SUB	204Fh 01h	HR	303
brake engage time	UNS16	DRS4	ms	0	0÷65535	INDEX SUB	204Fh 02h	HR	304

4.7.2. CONFIGURATION

To use electromechanical brake through the drive, is first of all necessary to connect the power output to the brake internal module through *AUX PWM OUT 1 SEL* (if brake is connected to power output #1) or *AUX PWM OUT 2 SEL* (if brake is connected to power output #2).

$$AUX\ PWM\ OUT\ 1\ SEL = 1$$

Connect the internal brake handler to power output #1.

$$AUX\ PWM\ OUT\ 2\ SEL = 1$$

Connect the internal brake handler to power output #2.

Brake value must be set with the duty cycle that commands the on state of the MOS that controls the current flowing on the brake (open drain MOSFET).

When the state of DS402 becomes *Operation enabled*, after a waiting time defined in *brake disengage time*, brake is disinserted. *brake disengage time* permits to disinsert brake only when the engine delivers sufficient torque to keep the load stable, this is fundamental for example in the applications involving a suspended load. It is possible to disinsert brake only if there are not errors and if TDI is enabled (refer to chapter 3.4.4).

When the state of DS402 becomes different from *Operation enabled*, after a waiting time defined in *brake engage time*, brake is engaged. In case of fault or if TDI becomes disabled, brake is engaged.

The operation described above defines the normal brake behavior (selectable by setting *BRAKE 1 MODE SEL* to 0). It is possible to engage and disengage brake in others conditions.

If *BRAKE 1 MODE SEL* is set to 1, brake is disengaged and engaged in function of the DS402 state and the coils value (from BKS1 to BKS9). If a coil is set to 1, in the corresponding state of the ds402, brake is disinserted. Vice versa if the coil is set to 0, in the corresponding state of the ds402, brake is engaged. For example, if the DS402 state machine is in *operation enabled* state and *OPERATION ENABLED* (BKS6) coil is set to 1, then the brake is disinserted. In this configuration *brake disengage time* and *brake engage time* are not used.

If *BRAKE 1 MODE SEL* is set to 2, brake is engaged and disengaged in the same condition of the case *BRAKE 1 MODE SEL* equal to 0, but brake is also engaged when the actual value of the controlled variable is 0.

Enabling *Brake activation* is possible to directly control the brake. When *Brake activation* is enabled brake are controlled by the state of *Brake value*. If *Brake value* is 1 then brake is disinserted, viceversa if it is 0, brake is engaged. When *Brake activation* is enabled, the other brake management modes are overwritten.

EXAMPLE: in an application in a motor is mounted a brake with engage and disengae time equal to 10 ms. Brake is connected to the power output 1 of the drive. In this application is necessary to engage brake when *Velocity actual value* is 0, in case of fault and when the power stage is disabled. parameters must be configured as follow:

AUX PWM OUT 1 SEL = 1

Brake value = 95

BRAKE 1 MODE SEL = 2

brake disengage time = 10

brake engage time = 10

4.8. Start-up option

With AZ3 it is possible to configure which status of the DS402 reach at the power on of the device.

4.8.1.PARAMETERS

Variable	Type	Code	Unit	Default	Range	Can open address		Modbus logical address	
Ready to switch on is reached at start up	COIL	DRF2	-	0	-	INDEX SUB	2019h (bit 1)	COIL	18
Operation enabled is reached at start up	COIL	DRF3	-	0	-	INDEX SUB	2019h (bit 2)	COIL	19

4.8.2.CONFIGURATION

At the start-up of AZ3, when power is provided to the drive, three possible DS402 states (refer to chapter 5.4) can be reached in function of the state of *Ready to switch on is reached at start up* and *Operation enabled is reached at start up*.

If no one of this flags are set to 1, then at the start up the drive reaches the DS402 state “Switch on disabled”.

When *Ready to switch on is reached at start up* is set to 1, then the drive reach the DS402 state “Ready to switch on”, when instead *Operation enabled is reached at start up* is set to 1 (or when this two flags are both set to 1), the drive reach the DS402 state “Operation enabled”.

4.9. TDI option

With AZ3 is possible to configure the drive behaviours in function of the state of the TDI (refer to chapter 3.4.4).

4.9.1.PARAMETERS

Variable	Type	Code	Unit	Default	Range	Can open address		Modbus logical address	
TDI CW mode	UNS8	SCM1	-	0	0÷255	INDEX SUB	204Eh 01h	HR	173L
TDI CW manage enable	COIL	DRF1	-	0	-	INDEX SUB	2019h (bit 0)	COIL	17

4.9.2.CONFIGURATIONS

The *TDI CW manage enable* flag must be set to 1 in order to control the drive with TDI. *TDI CW mode* must be set in function of the DS402 state (refer to chapter 5.4) to be reached.

- 0: ready to switch on.
- 1: switch on.
- 2: operation enabled.

4.10. Braking behaviour

It is possible to configure the behaviours of the drive when it works like a generator.

4.10.1. PARAMETERS

Variable	Type	Code	Unit	Default	Range	Can open address		Modbus logical address	
Braking resistor value	FLOAT	BR1	Ω	0	0÷1.0E9	INDEX SUB	2053h 01h	HR	314 315
Braking resistor max power	FLOAT	BR2	W	0	0÷1.0E9	INDEX SUB	2053h 03h	HR	316 317
AUX PWM OUT 1 SEL	UNS8	AXO1	-	0	0÷5	INDEX SUB	204Eh 05h	HR	266L
AUX PWM OUT 2 SEL	UNS8	AXO2	-	0	0÷5	INDEX SUB	204Eh 06h	HR	266H
V bus max*	FLOAT	DD1	V	60	0÷100	INDEX SUB	203Dh	HR	60 61
Nominal current rms*	FLOAT	IC1	A	30	-100÷100	INDEX SUB	203Eh	HR	68 69
Motor rated torque*	UNS32	TC4	mNm	2300	0÷1.0E9	INDEX SUB	6076h	HR	273 274
Motor rated current*	UNS32	TC5	mA	16000	0÷1.0E9	INDEX SUB	6075h	HR	275 276
Alimentation power*	FLOAT	AD1	W	3.36	0÷1.0E6	INDEX SUB	2053h 02h	HR	318 319

*These parameters once changed, must be saved. The new value assigned to this parameter will become operational only after a power reset.

4.10.2. CONFIGURATIONS

Az3 takes care to limit the braking in order to avoid that the engine regenerates more energy than can be dissipated. In order to protect the drive is necessary that the following data are correctly inserted.

Drive data:

- *V bus max*: it is the maximum value of tension that can be reached by the drive. This value must be set in function of the alimentation. Do not exceed over 60V.
- *Nominal current rms*: nominal current of the drive. It is fixed to 30 and is recommended to do not change it.
- *Alimentation power*: Drive alimentation absorption. It represents the consumption of the drive with power disabled.

Motor data:

- *Motor rated torque*: rated torque of the motor.
- *Motor rated current*: rated current of the motor.

To improve the braking performance it is possible to connect to the drive a braking resistor (refer to chapter 3.4.2).

It is possible to connect the braking resistor to both the power outputs and to connect it to the resistor internal handler through *AUX PWM OUT 1 SEL* (if brake is connected to power output #1) or *AUX PWM OUT 2 SEL* (if brake is connected to power output #2).

AUX PWM OUT 1 SEL = 3

Connects the internal resistor handler to power output #1.

AUX PWM OUT 2 SEL = 3

Connects the internal resistor handler to power output #2.

To use correctly the drive and the braking resistor, *Braking resistor max power* and *Braking resistor value* must be set with braking resistor data.

EXAMPLE: in an application in order to improve the braking performance, a braking resistor of 10 Ω and 600W is connected to the power output 1 of the drive.

AUX PWM OUT 1 SEL = 3

Braking resistor value = 10

Braking resistor max power = 600

4.11. Emulated encoder

AZ3 can provide the encoder emulated signal as output.

4.11.1. PARAMETERS

Variable	Type	Code	Unit	Default	Range	Can open address		Modbus logical address	
Encoder feedback* mode	UNS8	EFM1	-	0	0÷255	INDEX SUB	204Eh 04h	HR	188L

*These parameters once changed, must be saved. The new value assigned to this parameter will become operational only after a power reset.

4.11.2. CONFIGURATIONS

To activate the encoder emulated, set to 1 output *Encoder feedback mode*, save the value and then restart the drive.

4.12. Motor thermistor

AZ3 can handle motor thermistor.

4.12.1. PARAMETERS

Variable	Type	Code	Unit	Default	Range	Can open address		Modbus logical address	
Thermistor check activation	COIL	DRF7	-	0	-	INDEX SUB	2019h (bit 6)	COIL	23

4.12.2. CONFIGURATIONS

It is possible to connect to AZ3 the thermistor of motor in order to check motor temperature. Setting to 1 *Thermistor check activation* the motor temperature control is automatically activated. AZ3 is configured to support thermistor with a temperature-resistance characteristic according DIN44081/DIN44082.

4.13. Torque limit

In speed mode and in position mode is possible to check the maximum torque supplied by the drive.

4.13.1. PARAMETERS

Variable	Type	Code	Unit	Default	Range	Can open address		Modbus logical address	
Torque limit on	COIL	DF15	-	0	-	INDEX SUB	2018h (bit 14)	COIL	23
Torque limit	FLOAT	TF1	-	50.0		INDEX SUB	2009h 00h	HR	161
Motor rated torque	UNS32	TC4	mNm	2300	0÷1.0E9	INDEX SUB	6076h	HR	273 274
Motor rated current	UNS32	TC5	mA	16000	0÷1.0E9	INDEX SUB	6075h	HR	275 276

4.13.2. CONFIGURATIONS

It is possible to activate this check, setting to 1 *Torque limit on*. When the torque applied by the drive becomes higher than the value of *Torque limit*, *Control word* is set to 6 (power stage disabled).

Motor rated torque and *Motor rated current* must be set in function of the motor nameplate data as described in chapter 4.2.

5. OPERATING MODES



Read carefully the safety precautions reported in chapter 1.3 and in chapter 1.4 before wiring operations!

AZ3 could support the following operating modes.

- Profile velocity mode
- Profile position mode
- Profile Torque mode

This operating mode follow the specification of DS402. It is possible to commands the drive through the operating modes using TEM interface (refer to TEM interface manual).

5.1. Profile velocity mode

This operating mode permits the velocity control of the motor also in conditions of load changes.

5.1.1.PARAMETERS

Variable	Type	Code	Unit	Default	Range	Can open address		Modbus logical address	
Control word	UNS16	CM1	-	0	0÷65535	INDEX SUB	6040h 00h	HR	156
Modes of operation*	S8	CM2	-	3	-128÷127	INDEX SUB	6060h 00h	HR	157L
Target velocity	S32	CM4	User units	0	-2.0E6÷2.0E6	INDEX SUB	60FFh 00h	HR	158 159
Profile acceleration	UNS32	SF2	Speed user units/s	1000	0÷2.0E6	INDEX SUB	6083h 00h	HR	87 88
Profile deceleration	UNS32	PRF1	Speed user units/s	1000	0÷2.0E6	INDEX SUB	6084h 00h	HR	40 41
Invert speed feedback	COIL	DF7	-	0	-	INDEX SUB	2018h (bit 6)	COIL	7
Max profile velocity	UNS32	PC7	User units	3000	0÷2.0E6	INDEX SUB	607Fh 00h	HR	289 290
Velocity actual value	S32	MV7	User units	0	-2 E9÷2.0E9	INDEX SUB	606Ch 00h	IR	124 125

* This parameter once changed, will become operational only when power stage is disabled.

5.1.2.CONFIGURATION


To control the motor velocity through AZ3, *mode of operations* must be set to 3 as defined in DS402 specification.

Target velocity is the velocity set point and can be modified through CAN or Modbus, analog inputs (refer to chapter 4.4) and digital inputs (refer to chapter 4.5). *Max profile velocity* can be used in order to limit the set point velocity that can be set through *target velocity* (speed limits block in the image below).

Profile acceleration and *Profile deceleration* permits to modify the speed linear ramp (speed ramp block in the image below), they must be set according to the time within which the operating speed is to be reached.

Velocity actual value is the feedback of the actual velocity. Setting *Invert speed feedback* to 1, it is possible to invert the value read in *Velocity actual value*.

AZ3 *Profile velocity mode* control loop is showed in the image below.



5.2. Profile position mode

In profile position mode the drive control the position of the shaft.

5.2.1.PARAMETERS

Variable	Type	Code	Unit	Default	Range	Can open address		Modbus logical address	
Control word	UNS16	CM1	-	0	0÷65535	INDEX SUB	6040h 00h	HR	156
Modes of operation*	S8	CM2	-	3	-128÷127	INDEX SUB	6060h 00h	HR	157L
Target position	S32	PC1	-	0	-1.0E18÷1.0E18	INDEX SUB	607Ah 00h	HR	279 280
Profile acceleration	UNS32	SF2	-	1000	0÷2.0E6	INDEX SUB	6083h 00h	HR	87 88
Profile deceleration	UNS32	PRF1	-	1000	0÷2.0E6	INDEX SUB	6084h 00h	HR	40 41
Invert Position feedback	COIL	DF5	-	0	-	INDEX SUB	2018h (bit 4)	COIL	5
Reset Position	COIL	DF12	-	0	-	INDEX SUB	2018h (bit 11)	COIL	12
Min position range limit	S32	PC2	-	-100000	-1.0E18÷1.0E18	INDEX SUB	607Bh 02h	HR	281 282
Max position range limit	S32	PC3	-	100000	-1.0E18÷1.0E18	INDEX SUB	607Bh 01h	HR	283 284
Soft min position limit	S32	PC4	-	0	-1.0E18÷1.0E18	INDEX SUB	607Dh 01h	HR	285 286
Soft max position limit	S32	PC5	-	0	-1.0E18÷1.0E18	INDEX SUB	607Dh 02h	HR	287 288
Max profile velocity	UNS32	PC6	-	3000	0÷2.0E6	INDEX SUB	607Fh 00h	HR	289 290
Profile velocity	UNS32	PC7	-	1000	0÷2.0E6	INDEX SUB	6081h 00h	HR	291 292
Position actual value	S32	MV5	-	0	-2 E9÷2.0E9	INDEX SUB	6064h 00h	IR	121 122

* This parameter once changed, will become operational only when power stage is disabled.

5.2.2.CONFIGURATIONS

To control the shaft position through AZ3, *mode of operations* must be set to 1 as defined in DS402 specification.


Target position is the position set point and can be modified through CAN or Modbus, analog inputs (refer to chapter 4.4) and digital inputs (refer to chapter 4.5).

Soft min position limit and *Soft max position limit* define the absolute position limits for the *Target position* and the *Position actual value*. If the shaft moves over these limits power stage is disabled. *Min position range limit* and *Max position range limit* shall limit the numerical range of *Target position*. This parameters are summarized in the position ramp block in the image below.

Position actual value is the feedback of the actual position. Setting *Invert position feedback* to 1, it is possible to invert the value read in *Position actual value*.

Profile acceleration, *Profile deceleration* and *Max profile velocity* have the same functions that in Profile velocity mode. *Profile velocity* defines the operating speed used in order to reach *Target position*.

AZ3 Profile position mode control loop is showed in the image below.



5.3. Profile torque mode

Profile torque mode is used in order to control the torque applied to the load.

5.3.1. PARAMETERS

Variable	Type	Code	Unit	Default	Range	Can open address		Modbus logical address	
Control word	UNS16	CM1	-	0	0÷65535	INDEX SUB	6040h 00h	HR	156
Modes of operation*	S8	CM2	-	3	-128÷127	INDEX SUB	6060h 00h	HR	157L
Target torque	S16	TC1	% of rated torque	0	-10000÷10000	INDEX SUB	6071h	HR	270
Max torque	UNS16	TC2	% of rated torque	10000	0÷10000	INDEX SUB	6072h	HR	271
Max current	UNS16	TC3	% of rated current	10000	0÷10000	INDEX SUB	6073h	HR	272
Motor rated torque**	UNS32	TC4	mNm	2300	0÷1.0E9	INDEX SUB	6076h	HR	273 274
Motor rated current**	UNS32	TC5	mA	16000	0÷1.0E9	INDEX SUB	6075h	HR	275 276
Torque slope	UNS32	TC6	% of rated torque/s	1000	0÷1.0E9	INDEX SUB	6087h	HR	277 278
Torque actual value	S16	MV1	% of rated torque	0	-10000÷10000	INDEX SUB	6077h	IR	116

* This parameter once changed, will become operational only when power stage is disabled.

**These parameters once changed, must be saved. The new value assigned to this parameter will become operational only after a power reset.

5.3.2. CONFIGURATIONS


To control the motor torque through AZ3, mode of operations must be set to 4 as defined in DS402 specification. In order to make operative the change in operating mode, power stage must be disabled (refer to chapter 5.4).

Target torque is the torque set point and can be modified through CAN or Modbus, analog inputs (refer to chapter 4.4) and digital inputs (refer to chapter 4.5).

Torque slope permits to modify the torque linear ramp, it must be set according to the time within which the operating torque is to be reached (torque ramp block in the image below).

Max torque indicate the maximum value of *Target torque* configurable. *Max current* defines the maximum current that can be generated in function of the configured *Target torque* (torque limits block in the image below).

AZ3 Profile Torque mode control loop is showed in the image below.



5.4. Drive commands

AZ3 firmware is based on DS402 state machine.


5.4.1. PARAMETERS

Variable	Type	Code	Unit	Default	Range	Can open address	Modbus logical address
Control word	UNS16	CM1	-	0	0÷65535	INDEX SUB 6040h 00h	HR 156
Status word	UNS16	SW1	-	0	0÷65535	INDEX SUB 6041h 00h	IR 26
Shutdown option code	S16	DRS6	-	1	-32768÷32767	INDEX SUB 605Bh	HR 306
Disable operation option code	S16	DRS7	-	1	-32768÷32767	INDEX SUB 605Ch	HR 307

5.4.2. CONFIGURATIONS

Control word move the DS402 state machine from a state to another.

- *Control word* = SHUTDOWN_CODE = 6 (red transitions in the image below)
- *Control word* = SWITCHON_CODE = 7 (green transitions in the image below)
- *Control word* = SWITCHON_ENABLEOP_CODE = 15 (yellows transition in the image below)
- *Control word* = DISABLE_VOLTAGE_CODE = 0 (blue transitions in the image below)
- *Control word* = QUICK_STOP_CODE = 2 (orange transition in the image below)
- *Control word* = DISABLE_OP_CODE = 7 (green transitions in the image below)
- *Control word* = ENABLE_OP_CODE = 15 (yellow transitions in the image below)
- AUTOMATIC TRANSITION (black transitions in the image below)



Operation enable is the only state in which the power stage is enabled.

Using *Shutdown option code* it is possible to define the drive behaviours in transition 8. If *Shutdown option code* is equal to 1, then drive set the controlled variable (speed in Profile velocity mode and Profile position mode, torque in profile torque mode) to 0 and perform a linear ramp. If *Shutdown option code* is equal to 0 then the drive directly disable power stage without controlling the controlled variable.

Disable operation option code does the same operation in transition 5.

Status word permits to check the actual state of the DS402 states machine.

Status word	DS402 state machine
xxxx xxxx x0xx 0000	Not ready to switch on
xxxx xxxx x1xx 0000	Switch on disabled
xxxx xxxx x01x 0001	Ready to switch on
xxxx xxxx x01x 0011	Switched on
xxxx xxxx x01x 0111	Operation enabled
xxxx xxxx x00x 0111	Quick stop active
xxxx xxxx x0xx 1111	Fault reaction active
xxxx xxxx x0xx 1000	Fault

5.5. PID tuning

The drive control loops must be tuned in order to make the system work properly.

For current PID tuning use the analytical way or contact your TEM distributor.

The parameters to configure for ID loop tuning are:

Variable	Type	Code	Unit	Default	Range	Can open address		Modbus logical address	
ID KP	FLOAT	IDP1	-	0.2	-1.0E21÷1.0E21	INDEX SUB	202Ch	HR	14 15
ID KI	FLOAT	IDP2	-	200.0	-1.0E21÷1.0E21	INDEX SUB	202Dh	HR	16 17
ID KD	FLOAT	IDP1		0	-1.0E21÷1.0E21	INDEX SUB	202Eh	HR	18 19

The parameters to configure for IQ loop tuning are:

Variable	Type	Code	Unit	Default	Range	Can open address		Modbus logical address	
IQ KP	FLOAT	IQP1	-	0.2	-1.0E21÷1.0E21	INDEX SUB	202Fh	HR	24 25
IQ KI	FLOAT	IQP2	-	200.0	-1.0E21÷1.0E21	INDEX SUB	2030h	HR	26 27
IQ KD	FLOAT	IQP1		0	-1.0E21÷1.0E21	INDEX SUB	2031h	HR	28 29

For speed PID and position PID tuning, contact your TEM distributor or use TEM interface (refer to TEM interface manual).

The parameters to configure for speed loop tuning are:

Variable	Type	Code	Unit	Default	Range	Can open address		Modbus logical address	
SPEED KP	FLOAT	SP1	-	0.001	-1.0E21÷1.0E21	INDEX SUB	2032h	HR	34 35
SPEED KI	FLOAT	SP2	-	0.02	-1.0E21÷1.0E21	INDEX SUB	2033h	HR	36 37
SPEED KD	FLOAT	SP1		0	-1.0E21÷1.0E21	INDEX SUB	2034h	HR	38 39

The parameters to configure for position loop tuning are:

Variable	Type	Code	Unit	Default	Range	Can open address		Modbus logical address	
POSITION KP	FLOAT	PC8	-	1.0	-1.0E21÷1.0E21	INDEX SUB	2035h	HR	293 294
POSITION KI	FLOAT	PC9	-	0	-1.0E21÷1.0E21	INDEX SUB	2036h	HR	295 296
POSITION KD	FLOAT	PC10		0	-1.0E21÷1.0E21	INDEX SUB	2037h	HR	297 298

6. PARAMETERS TABLE

In the following tables are summarized the configurable variables divided as holding registers, input registers and coils registers (in CAN open standard this division has not functional utilities).

6.1. Holding registers

Variable	Type	Code	Unit	Default	Range	Can open address	Modbus logical address
ID KP	FLOAT	IDP1	-	0.2	-1.0E21÷1.0E21	INDEX SUB 202Ch	HR 14 15
ID KI	FLOAT	IDP2	-	200.0	-1.0E21÷1.0E21	INDEX SUB 202Dh	HR 16 17
ID KD	FLOAT	IDP1		0	-1.0E21÷1.0E21	INDEX SUB 202Eh	HR 18 19
IQ KP	FLOAT	IQP1	-	0.2	-1.0E21÷1.0E21	INDEX SUB 202Fh	HR 24 25
IQ KI	FLOAT	IQP2	-	200.0	-1.0E21÷1.0E21	INDEX SUB 2030h	HR 26 27
IQ KD	FLOAT	IQP1		0	-1.0E21÷1.0E21	INDEX SUB 2031h	HR 28 29
SPEED KP	FLOAT	SP1	-	0.001	-1.0E21÷1.0E21	INDEX SUB 2032h	HR 34 35
SPEED KI	FLOAT	SP2	-	0.02	-1.0E21÷1.0E21	INDEX SUB 2033h	HR 36 37
SPEED KD	FLOAT	SP1		0	-1.0E21÷1.0E21	INDEX SUB 2034h	HR 38 39
Profile deceleration	UNS32	PRF1	Speed user units/s	1000	0÷2.0E6	INDEX SUB 6084h 00h	HR 40 41
V bus max	FLOAT	DD1	V	60	0÷100	INDEX SUB 203Dh	HR 60 61
ENCODER TYPE	UNS16	DD2	-	0	0÷10	INDEX SUB 2039h	HR 62
SET POINT SELECTOR	S16	DD3	-	0	0÷10	INDEX SUB 2038h	HR 63
MOTOR POLES PAIR	UNS16	DD5	-	4	0÷16	INDEX SUB 203Ah	HR 65
Nominal current rms	FLOAT	IC1	A	30	-100÷100	INDEX SUB 203Eh	HR 68 69
Max motor speed	UNS32	SF1	User units	3000	0÷2.0E6	INDEX SUB 6080h	HR 85 86
Profile acceleration	UNS32	SF2	Speed user units/s	1000	0÷2.0E6	INDEX SUB 6083h	HR 87 88
Gear ratio motor revolution	UNS32	FS1	rounds	1	0÷400000	INDEX SUB 6091h 01h	HR 89 90
Gear ratio shaft revolutions	UNS32	FS2	rounds	1	0÷400000	INDEX SUB 6091h 02h	HR 91 92
Velocity encoder resolution motor revolutions	UNS32	FS3	round/s	1	0÷400000	INDEX SUB 6090h 02h	HR 93 94
Velocity encoder resolution increments per second	UNS32	FS4	Incr/s	8192	0÷400000	INDEX SUB 6090h 01h	HR 95 96
Feed constant feed	UNS32	FS5	-	1	0÷400000	INDEX SUB 6092h 01h	HR 97 98

Variable	Type	Code	Unit	Default	Range	Can open address		Modbus logical address	
Feed constant shaft revolutions	UNS32	FS6	rounds	1	0÷400000	INDEX SUB	6092h 02h	HR	99 100
Position encoder resolution motor revolutions	UNS32	FS9	rounds	1	0÷400000	INDEX SUB	608Fh 02h	HR	105 106
Position encoder resolutions encoder increments	UNS32	FS10	-	8192	0÷400000	INDEX SUB	608Fh 01h	HR	107 108
Velocity factor numerator	S16	FS11	-	60	0÷32767	INDEX SUB	6094h 01h	HR	109
Velocity factor denominator	S16	FS12	-	1	0÷32767	INDEX SUB	6094h 02h	HR	110
Polarity	UNS16	FS13	-	0	0÷65536	INDEX SUB	607Eh	HR	111
Control word	UNS16	CM1	-	0	0÷65535	INDEX SUB	6040h	HR	156
Modes of operation	S8	CM2	-	3	-128÷127	INDEX SUB	6060h	HR	157L
Feed constant shaft revolutions	UNS32	FS6	rounds	1	0÷400000	INDEX SUB	6092h 02h	HR	99 100
Target velocity	S32	CM4	User units	0	-2.0E6÷2.0E6	INDEX SUB	60FFh	HR	158 159
TDI CW mode	UNS8	SCM1	-	0	0÷255	INDEX SUB	204Eh 01h	HR	173L
Motor type	UNS16	MTY1	-	10	0÷65535	INDEX SUB	6402h	HR	176
Encoder phase displacement	FLOAT	PHC3	[rad]	3.14	-6.28÷6.28	INDEX SUB	2052h 03h	HR	185 186
Output 1 selector	UNS8	OF1	-	0	0÷255	INDEX SUB	204Eh 02h	HR	187L
Output 2 selector	UNS8	OF2	-	0	0÷255	INDEX SUB	204Eh 03h	HR	187H
Encoder feedback mode	UNS8	EFM1	-	0	0÷255	INDEX SUB	204Eh 04h	HR	188L
User range 1	FLOAT	AI1	-	1000	-1.0E9÷1.0E9	INDEX SUB	2045h 02h	HR	249 250
Offset 1	FLOAT	AI2	-	0	-1.0E9÷1.0E9	INDEX SUB	2045h 03h	HR	251 252
Zero threshold 1	UNS16	AI3	-	5	0÷65535	INDEX SUB	2045h 04h	HR	253
User range 2	FLOAT	AI4	-	1000	-1.0E9÷1.0E9	INDEX SUB	2046h 02h	HR	254 255
Offset 2	FLOAT	AI5	-	-500	-1.0E9÷1.0E9	INDEX SUB	2046h 03h	HR	256 257
Zero threshold 2	UNS16	AI6	-	1	0÷65535	INDEX SUB	2046h 04h	HR	258
Selector 1	UNS8	AI7	-	2	0÷255	INDEX SUB	2045h 01h	HR	259L
Selector 2	UNS8	AI8	-	4	0÷255	INDEX SUB	2046h 01h	HR	259H
AI Mult 1	FLOAT	AI9	-	0.1	-1.0E9÷1.0E9	INDEX SUB	-	HR	260 261
AI Mult 2	FLOAT	AI10	-	0.9	-1.0E9÷1.0E9	INDEX SUB	-	HR	262 263

Variable	Type	Code	Unit	Default	Range	Can open address		Modbus logical address	
AI filter time	UNS32	AI11	0.1*ms	10	0÷200000	INDEX SUB	-	HR	264 265
AUX PWM OUT 1 SEL	UNS8	AXO1	-	0	0÷5	INDEX SUB	204Eh 05h	HR	266L
AUX PWM OUT 2 SEL	UNS8	AXO2	-	0	0÷5	INDEX SUB	204Eh 06h	HR	266H
BRAKE 1 MODE SEL	UNS8	AXO3	-	1	0÷100	INDEX SUB	204Eh 07h	HR	267L
BRAKE 1 POW VALUE	UNS8	AXO4	%	100	0÷5	INDEX SUB	204Fh 02h	HR	267H
Target torque	S16	TC1	% of rated torque	0	-10000÷10000	INDEX SUB	6071h	HR	270
Max torque	UNS16	TC2	% of rated torque	10000	0÷10000	INDEX SUB	6072h	HR	271
Max current	UNS16	TC3	% of rated current	10000	0÷10000	INDEX SUB	6073h	HR	272
Motor rated torque	UNS32	TC4	mNm	2300	0÷1.0E9	INDEX SUB	6076h	HR	273 274
Motor rated current	UNS32	TC5	mA	16000	0÷1.0E9	INDEX SUB	6075h	HR	275 276
Torque slope	UNS32	TC6	% of rated torque/s	1000	0÷1.0E9	INDEX SUB	6087h	HR	277 278
Target position	S32	PC1	-	0	-1.0E18÷1.0E18	INDEX SUB	607Ah	HR	279 280
Min position range limit	S32	PC2	-	-100000	-1.0E18÷1.0E18	INDEX SUB	607Bh 02h	HR	281 282
Max position range limit	S32	PC3	-	100000	-1.0E18÷1.0E18	INDEX SUB	607Bh 01h	HR	283 284
Soft min position limit	S32	PC4	-	0	-1.0E18÷1.0E18	INDEX SUB	607Dh 01h	HR	285 286
Soft max position limit	S32	PC5	-	0	-1.0E18÷1.0E18	INDEX SUB	607Dh 02h	HR	287 288
Max profile velocity	UNS32	PC6	User units	3000	0÷2.0E6	INDEX SUB	607Fh	HR	289 290
Profile velocity	UNS32	PC7	-	1000	0÷2.0E6	INDEX SUB	6081h	HR	291 292
POSITION KP	FLOAT	PC8	-	1.0	-1.0E21÷1.0E21	INDEX SUB	2035h	HR	293 294
POSITION KI	FLOAT	PC9	-	0	-1.0E21÷1.0E21	INDEX SUB	2036h	HR	295 296
POSITION KD	FLOAT	PC10	-	0	-1.0E21÷1.0E21	INDEX SUB	2037h	HR	297 298
brake disengage time	UNS16	DRS3	ms	0	0÷65535	INDEX SUB	204Fh 01h	HR	303
brake engage time	UNS16	DRS4	ms	0	0÷65535	INDEX SUB	204Fh 02h	HR	304
Shutdown option code	S16	DRS6	-	1	-32768÷32767	INDEX SUB	605Bh	HR	306
Disable operation option code	S16	DRS7	-	1	-32768÷32767	INDEX SUB	605Ch	HR	307
Braking resistor value	FLOAT	BR1	Ω	0	0÷1.0E9	INDEX SUB	2053h 01h	HR	314 315

Variable	Type	Code	Unit	Default	Range	Can open address		Modbus logical address	
Braking resistor max power	FLOAT	BR2	W	0	0÷1.0E9	INDEX SUB	2053h 03h	HR	316 317
Alimentation power	FLOAT	AD1	W	3.36	0÷1.0E6	INDEX SUB	2053h 02h	HR	318 319
DI1 rise selector	UNS8	DI1	-	0	0÷255	INDEX SUB	2047h 01h	HR	320L
DI1 fall selector	UNS8	DI2	-	0	0÷255	INDEX SUB	2047h 02h	HR	320H
DI2 rise selector	UNS8	DI3	-	0	0÷255	INDEX SUB	2047h 03h	HR	321L
DI2 fall selector	UNS8	DI4	-	0	0÷255	INDEX SUB	2047h 04h	HR	321H
DI3 rise selector	UNS8	DI5	-	0	0÷255	INDEX SUB	2047h 05h	HR	322L
DI3 fall selector	UNS8	DI6	-	0	0÷255	INDEX SUB	2047h 06h	HR	322H
DI4 rise selector	UNS8	DI7	-	0	0÷255	INDEX SUB	2047h 07h	HR	323L
DI4 fall selector	UNS8	DI8	-	0	0÷255	INDEX SUB	2047h 08h	HR	323H
Speed value 1	S32	DI9	-	0	-1.0E9÷1.0E9	INDEX SUB	2048h	HR	324 325
Speed value 2	S32	DI10	-	0	-1.0E9÷1.0E9	INDEX SUB	2049h	HR	326 327
Position value 1	S32	DI11	-	0	-1.0E12÷1.0E12	INDEX SUB	204Ah	HR	328 329
Position value 2	S32	DI12	-	0	-1.0E12÷1.0E12	INDEX SUB	204Bh	HR	330 331
Torque value 1	S16	DI13	-	0	-10000÷10000	INDEX SUB	204Ch	HR	332
Torque value 2	S16	DI14	-	0	-10000÷10000	INDEX SUB	204Dh	HR	333
Store all parameters	UNS16	SV1	-	0	0÷1.0E9	INDEX SUB	1010h 01h	HR	449 450

6.2. Input registers


Variable	Type	Code	Unit	Default	Range	Can open address		Modbus logical address	
Status word	UNS16	SW1	-	0	0÷65535	INDEX SUB	6041h	IR	26
RAM errors counter	UNS8	DLH4	-	0	0÷255	INDEX SUB	2057h 06h	IR	39L
RAM index	UNS8	DLH5	-	0	0÷255	INDEX SUB	2057h 07h	IR	39H
Error code 1	UNS16	DRL1	-	0	0÷65535	INDEX SUB	205Ah 01h	IR	48
Error code 2	UNS16	DRL2	-	0	0÷65535	INDEX SUB	205Bh 01h	IR	55
Error code 3	UNS16	DRL3	-	0	0÷65535	INDEX SUB	205Ch 01h	IR	62
Error code 4	UNS16	DRL4	-	0	0÷65535	INDEX SUB	205Dh 01h	IR	69
Error code 5	UNS16	DRL5	-	0	0÷65535	INDEX SUB	205Eh 01h	IR	76
Error code 6	UNS16	DRL6	-	0	0÷65535	INDEX SUB	205Fh 01h	IR	83
Error code 7	UNS16	DRL7	-	0	0÷65535	INDEX SUB	2060h 01h	IR	90
Error code 8	UNS16	DRL8	-	0	0÷65535	INDEX SUB	2061h 01h	IR	97
Torque actual value	S16	MV1	% of rated torque	0	-10000÷10000	INDEX SUB	6077h	IR	116
Position actual value	S32	MV5	-	0	-2 E9÷2.0E9	INDEX SUB	6064h	IR	121 122
Velocity actual value	S32	MV7	-	0	-2 E9÷2.0E9	INDEX SUB	606Ch	IR	124 125

6.3. Coils

Variable	Type	Code	Unit	Default	Range	Can open address		Modbus logical address	
Phasing in progress	COIL	DF1	-	0	-	INDEX SUB	2018h (bit 0)	COIL	1
Start phasing	COIL	DF2	-	0	-	INDEX SUB	2018h (bit 1)	COIL	2
Invert Position feedback	COIL	DF5	-	0	-	INDEX SUB	2018h (bit 4)	COIL	5
auto-phased motor	COIL	DF6	-	0	-	INDEX SUB	2018h (bit 5)	COIL	6
Invert speed feedback	COIL	DF7	-	0	-	INDEX SUB	2018h (bit 6)	COIL	7
TDI CW manage enable	COIL	DRF1	-	0	-	INDEX SUB	2019h (bit 0)	COIL	17
Ready to switch on is reached at start up	COIL	DRF2	-	0	-	INDEX SUB	2019h (bit 1)	COIL	18
Operation enabled is reached at start up	COIL	DRF3	-	0	-	INDEX SUB	2019h (bit 2)	COIL	19
Brake activation	COIL	DRF8	-	0	-	INDEX SUB	2019h (bit 7)	COIL	24
Brake value	COIL	DRF9	-	0	-	INDEX SUB	2019h (bit 8)	COIL	25
EEPROM autophasing data cleaning	COIL	DRF11	-	0	-	INDEX SUB	2019h (bit 10)	COIL	27
EEPROM parameters cleaning	COIL	DRF12	-	0	-	INDEX SUB	2019h (bit 11)	COIL	28
EEPROM total cleaning	COIL	DRF13	-	0	-	INDEX SUB	2019h (bit 12)	COIL	29
START	COIL	BKS1	-	0	-	INDEX SUB	201Bh (bit 0)	COIL	81
NOT READY TO SWITCH ON	COIL	BKS2	-	0	-	INDEX SUB	201Bh (bit 1)	COIL	82
SWITCH ON DISABLED	COIL	BKS3	-	0	-	INDEX SUB	201Bh (bit 2)	COIL	82
READY TO SWITCH ON	COIL	BKS4	-	0	-	INDEX SUB	201Bh (bit 3)	COIL	83
SWITCHED ON	COIL	BKS5	-	0	-	INDEX SUB	201Bh (bit 4)	COIL	84
OPERATION ENABLED	COIL	BKS6	-	1	-	INDEX SUB	201Bh (bit 5)	COIL	85
QUICK STOP ACTIVE	COIL	BKS7	-	0	-	INDEX SUB	201Bh (bit 6)	COIL	86
FAULT	COIL	BKS8	-	0	-	INDEX SUB	201Bh (bit 7)	COIL	87
FAULT REACTION ACTIVE	COIL	BKS9	-	0	-	INDEX SUB	201Bh (bit 8)	COIL	88

7. ERRORS AND DIAGNOSTICS

The drive monitors the working parameters and generates alarms or errors when necessary, according to the values set in the alarm parameters; the drive informs the user about the active errors, by the multicolour LED. It is possible to reset the drive using PB button or digital input (refer to chapter 4.5), once the errors are debugged.



7.1. Parameters

Variable	Type	Code	Unit	Default	Range	Can open address		Modbus logical address	
RAM errors counter	UNS8	DLH4	-	0	0÷255	INDEX SUB	2057h 06h	IR	39L
RAM index	UNS8	DLH5	-	0	0÷255	INDEX SUB	2057h 07h	IR	39H
Error code 1	UNS16	DRL1	-	0	0÷65535	INDEX SUB	205Ah 01h	IR	48
Error code 2	UNS16	DRL2	-	0	0÷65535	INDEX SUB	205Bh 01h	IR	55
Error code 3	UNS16	DRL3	-	0	0÷65535	INDEX SUB	205Ch 01h	IR	62
Error code 4	UNS16	DRL4	-	0	0÷65535	INDEX SUB	205Dh 01h	IR	69
Error code 5	UNS16	DRL5	-	0	0÷65535	INDEX SUB	205Eh 01h	IR	76
Error code 6	UNS16	DRL6	-	0	0÷65535	INDEX SUB	205Fh 01h	IR	83
Error code 7	UNS16	DRL7	-	0	0÷65535	INDEX SUB	2060h 01h	IR	90
Error code 8	UNS16	DRL8	-	0	0÷65535	INDEX SUB	2061h 01h	IR	97

7.2. Diagnostic

Errors are diagnosed through led and through drive parameters.


The following table summarizes the possible errors with the corresponding code and with the corresponding LED colour:

LED colour	Code	Type
Blinking white	-	DRIVE OK
Blue	8257	ENCODER NOT CONNECTED
Blue	8258	OVER VOLTAGE ERROR
Purple	8259	UNDER VOLTAGE ERROR
Red	8260	OVER CURRENT U
Red	8261	OVER CURRENT V
Red	8262	OVER CURRENT W
Light blue	8263	OVER TEMPERATURE
Blue	8264	I2T ERROR
Light blue	8266	THERMISTOR ALARM ERROR
Yellow	Da 16449 a 24732	INTERNAL ERROR

To understand which error is currently active or which errors occurred during the current work cycle, is possible to check *Error code x* parameters.

To read correctly the errors RAM log, the circular buffer logic must be used. *RAM index* is the index of the error currently active (or of the last error occurred, if there are no active errors) and *RAM errors counter* is the number of errors in the log.

EXAMPLE: In the image below, an example of how the RAM log buffer works is showed.



8. TROUBLESHOOTING

To solve AZ3 errors is necessary knowing the error code. Errors code can be read either via RAM log or via Diagnostic panel in TEM interface (refer to TEM interface manual).

8.1. Parameters

Variable	Type	Code	Unit	Default	Range	Can open address		Modbus logical address	
EEPROM autophasing data cleaning	COIL	DRF11	-	0	-	INDEX SUB	2019h (bit 10)	COIL	27
EEPROM parameters cleaning	COIL	DRF12	-	0	-	INDEX SUB	2019h (bit 11)	COIL	28
EEPROM total cleaning	COIL	DRF13	-	0	-	INDEX SUB	2019h (bit 12)	COIL	29

8.2. Problem solving

Code	Possible causes	Suggested operations
8257	<ul style="list-style-type: none"> Problem in encoder's cables. 	<ul style="list-style-type: none"> Check that the encoder is correctly connected to the drive.
8258	<ul style="list-style-type: none"> Error in the wiring of the power supply. Errors in braking behaviour configuration (refer to chapter 4.10). 	<ul style="list-style-type: none"> Check the power supply voltage and compare it to the supply limits. Check the braking behaviour configuration (refer to chapter 4.10).
8259	<ul style="list-style-type: none"> Error in the wiring of the power supply. High current absorption of the board. 	<ul style="list-style-type: none"> Check the power supply voltage and compare it to the supply limits. Check the section and length of the power supply cables.
8260 8261 8262	<ul style="list-style-type: none"> Mechanical obstacle or too high friction. Errors in the wiring of the motors. 	<ul style="list-style-type: none"> Check that motor load is not blocked Check that the motor is correctly connected to the drive.
8263	<ul style="list-style-type: none"> The drive is working over its power capabilities. The drive cannot dissipate enough heat 	<ul style="list-style-type: none"> Reduce the service of the motor Check that the drive is installed correctly
8264	<ul style="list-style-type: none"> The drive is working in too high temperature condition 	<ul style="list-style-type: none"> Check the drive working environment
8266	<ul style="list-style-type: none"> The motor is working in too high temperature condition 	<ul style="list-style-type: none"> Check the motor working environment
16449	<ul style="list-style-type: none"> Firmware error type 1 	<ul style="list-style-type: none"> Contact your TEM Drive distributor
24641	<ul style="list-style-type: none"> Firmware error type 2 	<ul style="list-style-type: none"> Restart the drive
24706 to 24711 24713 to 24717 24719 to 24731	<ul style="list-style-type: none"> EEPROM parameters data corrupted 	<ul style="list-style-type: none"> Follow this operation: <ul style="list-style-type: none"> Restart the drive If the error persist <ul style="list-style-type: none"> Set <i>EEPROM parameters cleaning</i> (operation possible also via TEM Interface) in order to clean the pages of the memory corrupted. Reset Drive Reconfigure the drive If the error persist <ul style="list-style-type: none"> Set <i>EEPROM total cleaning</i> (operation possible also via TEM Interface) Reset Drive Reconfigure the drive If the motor was auto phased, re-execute the autophasing operation If error still persist contact you TEM Drive distributor

Code	Possible causes	Suggested operations
24712 24718	<ul style="list-style-type: none"> EEPROM phasing data corrupted 	<ul style="list-style-type: none"> Follow this operation: <ul style="list-style-type: none"> Restart the drive If the error persist <ul style="list-style-type: none"> Set <i>EEPROM autophasing data cleaning</i> (operation possible also via TEM Interface) in order to clean the pages of the memory corrupted. Reset Drive If the motor was auto phased, re-execute the autophasing operation If the error persist <ul style="list-style-type: none"> Set <i>EEPROM total cleaning</i> (operation possible also via TEM Interface) Reset Drive Reconfigure the drive If the motor was auto phased, re-execute the autophasing operation If error still persist contact you TEM Drive distributor
24705 24732	<ul style="list-style-type: none"> EEPROM corrupted 	<ul style="list-style-type: none"> Follow this operation: <ul style="list-style-type: none"> Restart the drive If the error persist <ul style="list-style-type: none"> Set <i>EEPROM total cleaning</i> (operation possible also via TEM Interface) Reset Drive Reconfigure the drive If the motor was auto phased, re-execute the autophasing operation If error still persist contact you TEM Drive distributor

9. MAINTENANCE AND INSPECTION



Read carefully the safety precautions reported in chapter 1.7 before maintaining and inspecting the drive!

Inspect periodically the drive to ensure that the environment is always appropriate to the drive operation and to detect any sign of failure or malfunctioning.

- Visually check that the environment where the drive is placed is not subject to large amounts of dust, traces of water or other liquids, traces of condensate. If any of these elements is to be found, improve the environment or reconsider the positioning of the drive.
- Check using a thermometer that the environment temperature is within the operation temperature limits. If it is not, improve the environment or reconsider the positioning of the drive.
- Check that the load current and the board temperature is not much different from the values measured during a normal operating cycle. If it is not, check that the mechanical system is not subjected to high frictions or overloading.
- Check that all mounting screws and screw terminals are tightened firmly; if any of them is loose, tighten it.

10. DISPOSAL



Read carefully the safety precautions reported in chapter 1.8 before disposing the drive!

Contact a specialized agent in industrial disposal respecting to the local regulations.



TEM Electric Motors S.r.l.

Via Berretta,1

42024 Castelnovo di Sotto (RE)

Phone +39 0522.68.27.23

P.I. IT01978390357